



keyboard trader™

Key Catalog



keyboard trader™

Category	Size	Price
A	1 x 1	\$ 1.25
B	1 x 1	\$ 2.50
C	1 x 1	\$ 3.75
D	2 x 1	\$ 2.50
E	2 x 1	\$ 3.75
F	2 x 1	\$ 5.00
G	1 x 2	\$ 3.75
H	2 x 2	\$ 3.75
I	2 x 2	\$ 6.25
J	2 x 2	\$ 7.50
K	2 x 2	\$10.00
L	Blank Spacer	\$ 0.60

Some keys are suggestive of functionality which is only possible with certain licenses of Keyboard Trader software, or which must be programmed using macros. All keys sold by Bionic Trader Systems fit the Cherry MX Switch.



A S1010



A S1020



A S1030



A S1040



A S1050



A S1060



A S1070



B S1080



B S1090



B S1100



B S1110



B S1120



B S1130



B S1140



B S1150



B S1160



B S1170



B S1180



B S1190



B S1200



B S1210



B S1220



B S1230



B S1240



B S1250



B S1260



B S1270



B S1280



B S1290



B S1300



B S1310



B S1320



B S1330



B S1340



B S1350




B S1360



B S1370




B S1380



B S1390



B S1400



B S1410



B S1420

SINGLE KEYS (1 x 1)



B S1430



B S1440



B S1450



B S1460



B S1470



B S1480



B S1490



B S1500



B S1510



B S1520



B S1530




B S1540



B S1550



B S1560



B S1570



B S1580



B S1590



B S1600



B S1610



B S1620



B S1630



B S1640



B S1650



B S1660



B S1670



B S1680



B S1690



B S1700



B S1710



B S1720



B S1730



B S1740



B S1750



B S1760



B S1770



B S1780



B S1790



B S1800



B S1810



B S1820



B S1830



B S1840

SINGLE KEYS (1 x 1)



B S1850



B S1860



B S1870



B S1880



B S1890



B S1900



B S1910



B S1920



B S1930



B S1940



B S1950



B S1960



B S1970



B S1980



B S1990



B S2000



B S2010



B S2020



B S2030



C S2040



C S2050



C S2060



C S2070



C S2080



C S2090



C S2100



C S2110



C S2120



C S2130



C S2140



C S2150



C S2160



C S2170



C S2180



C S2190



C S2200



C S2210



C S2220



C S2230



C S2240



C S2250



C S2260



C S2270



C S2280



C S2290



C S2300



C S2310



C S2320



C S2330



C S2340



C S2350



C S2360



C S2370



C S2380



C S2390



C S2400



C S2410



C S2420



C S2430



C S2440



C S2450



C S2460



C S2470



C S2480



C S2490



C S2500



C S2510



C S2520



C S2530



C S2540



C S2550



C S2560



B S2570



B S2580



keyboard trader™

SINGLE KEYS (1 x 1)



B C1010



B C1020



B C1030



B C1040



B C1050



B C1060



B C1070



B C1080



B C1090



B C1100



B C1110



B C1120



B C1130



B C1140



B C1150



B C1160



B C1170



B C1180



B C1190



B C1200



B C1210



B C1220



B C1230



B C1240



B C1250



B C1260



B C1270



B C1280



B C1290



B C1300



B C1310



B C1320



B C1330



B C1340



B C1350



B C1360



B C1370



B C1380



B C1390



B C1400



B C1410



B C1420

SINGLE KEYS (1 x 1)



B C1430



B C1440



B C1450



B C1460



B C1470



B C1480



B C1490



B C1500



B C1510



B C1520



B C1530



B C1540



B C1550



B C1560



B C1570



B C1580



B C1590



B C1600



B C1610



B C1620



B C1630



B C1640

BLANK SPACERS (1 x 1)



L B1010

DOUBLE KEYS (2 x 1)



D D1010



D D1020



D D1030




D D1040




D D1050



D D1060



D D1070



E D1080



E D1090



E D1100



E D1110



E D1120



E D1130



E D1140



E D1150



E D1160



E D1170



E D1180



E D1190




E D1200



E D1210



E D1220



E D1230




E D1240



keyboard trader™

DOUBLE KEYS (2 x 1)




E D1250




E D1260



E D1270



E D1280



E D1290



E D1300



E D1310



E D1320



E D1330



E D1340




E D1350



E D1360




E D1370



E D1380



E D1390



E D1400



E D1410



E D1420



E D1430



E D1440



E D1450



E D1460



E D1470



E D1480

DOUBLE KEYS (2 x 1)



E D1490



E D1500



E D1510



E D1520



E D1530



E D1540



E D1550



E D1560



E D1570



F D1580



F D1590



F D1600



F D1610



F D1620



F D1630



F D1640



F D1650



F D1660



F D1670



F D1680



F D1690



F D1700



F D1710



F D1720

DOUBLE KEYS (2 x 1)



F D1730



F D1740



F D1750



F D1760



F D1770



F D1780



F D1790



F D1800



F D1810



F D1820



F D1830



F D1840



F D1850



F D1860




E D1880



E D1890



G D1870



I Q1010



I Q1020



K Q1030



K Q1040



J Q1050



J Q1060




J Q1070



J Q1080



J Q1090



H Q1100



H Q1110



H Q1120



H Q1130



H Q1140



H Q1150



H Q1160

**I** Q1170**I** Q1180**J** Q1190**J** Q1200**J** Q1210